

SUMMARY

INTRODUCTION AND SET UP

MAIN SCREEN (MAIN)

AUDIO SYSTEM (AUDIO)

TELEPHONE (TEL)

NAVIGATION (NAV)

ON-BOARD COMPUTER (TRIP)

CLIMATE CONTROL (CLIMA)

STATUS MESSAGES, GENERALITIES AND TECHNICAL INFORMATION

LIST OF CONTENTS

1.	Introduction and set up	2.	Main display (MAIN)	4.1.2	PIN entry
1.1	I.C.S.: Alfa Romeo enhanced comfort and functionality	3.	Audio system (AUDIO)	4.2	Emergency call function
1.2	General instructions for use	3.1	Radio functions	4.3	Main function “manual dial”
1.3	Turning the I.C.S. On/Off and stand-by feature	3.1.1	Radio main function page	4.3.1	Entering a telephone number
1.3.1	Turning the engine on/off	3.1.2	Radio function controls	4.3.2	Calling the number
1.3.2	Through the volume control	3.1.3	Seeking and memorising stations	4.3.3	Ending the conversation and accepting calls
1.3.3	Stand-by feature	3.2	Cassette player functions	4.3.4	Handsfree feature, volume adjustment and additional receiver functions
1.4	Unit and navigation code	3.2.1	CC main function page	4.3.5	Other manual dialling functions
1.5	Brief instructions for the I.C.S.	3.2.2	Cassette player controls	4.4	Main “Phone book” function
1.5.1	Main screen (MAIN)	3.3	How the CD player works	4.4.1	Dialling a subscriber listed in the I.C.S. phone book
1.5.2	Audio system (AUDIO)	3.3.1	CD player main function page	4.4.2	Entering a new item
1.5.3	Telephone (TEL)	3.3.2	CD player controls	4.4.3	Deleting an item
1.5.4	Navigation (NAV)	3.4	Audio settings	4.4.4	Changing an item
1.5.5	On-board computer (TRIP)	3.4.1	Without DSP (Digital Sound Processing)	4.5	“Direct dial” main function
1.5.6	Climate control unit (CLIMA)	3.4.2	With DSP (Digital Sound Processing)	4.5.1	Dialling a subscriber listed in the “Direct dial” list
1.6	I.C.S. maintenance	4.	Telephone (TEL)		
1.7	System software updates	4.1	Preliminary operations		
		4.1.1	Inserting the telephone card		

4.5.2	Compiling the list of "Direct dial"	5.	Navigation (NAV)	5.5	Information page
4.5.3	Changing "Direct dial"	5.1	Destination entry	5.6	Indication of distance from destination and arrival time
4.6	"Last 5 numbers" main function	5.1.1	Entering the "Street address" field	5.7	Activating/deactivation the navigation function
4.6.1	Selecting an item from the "Last 5 no." list	5.1.2	Entering the destination "Intersection"		
4.7	"Calls list" main function	5.1.3	Entering the destination "Points of Interest"	6.	On-board computer (TRIP)
4.8	Telephone options	5.1.4	Entering the destination "Destination memory"	6.1	Request for statistical data
4.8.1	Telephone options - selecting "Info"	5.1.5	Entering the destination "Recent destinations"	6.1.1	"Journey data to destination"
4.8.2	Telephone options - selecting "SMS"	5.2	Route selection criteria	6.1.2	"Journey data from hh:min" and "Journey data continued"
4.8.3	Telephone options - selecting "Copy card"	5.2.1	"Alternative route"	6.2	I.C.S. system settings
4.8.4	Telephone options - selecting "Merge SIMs"	5.2.2	"Shortest time"	6.2.1	Language
4.8.5	Telephone options - selecting "Call divert"	5.2.3	"Prefer freeways"	6.2.2	Consumption
4.8.6	Telephone options - selecting "Settings"	5.2.4	"Avoid freeways"	6.2.3	Distance
4.9	"Call waiting" function	5.2.5	"OK"	6.2.4	Temperature
4.9.1	"Reject" option	5.2.6	"Cancel"	6.2.5	Limit
4.9.2	"Take call 1" option	5.3	Destination guidance and orientation help	6.2.6	Date/time
4.9.3	"End call 1" option	5.3.1	Voice instructions	6.2.7	Screen setting
4.9.4	"Take call 2" option	5.3.2	Graphic instructions	7.	Climate control (CLIMA)
4.9.5	"End call 2" option	5.3.3	Map representation	7.1	Equivalent temperature
4.9.6	"End all calls" option	5.4	Volume control	7.2	Description of controls

- 7.3 Description of operating strategies

- 8. Status messages, generalities and technical information
 - 8.1 Status messages-troubleshooting
 - 8.2 Generalities
 - 8.3 Technical information