

ALPHABETICAL INDEX

- A**BS system 117
- Brake Assist (brake assist in an emergency) 119
 - Warnings 140
- Accessories purchased by the owner 156
- Additional heater 88
- Maintenance 89
- Air bags, front and side 50
- Front air bag 50
 - General warning 55
 - Passenger side air bag disengagement 52-264
 - Side air bag 54
- Air cleaner 221
- Air conditioner 83
- Air conditioning 81
- Air conditioning controls 84
- Air vents 82-83
- Alarm system 22
- Cutting out the siren 25
- Alfa Romeo CODE system 16
- Alfa Romeo I.C.S. system (controls on steering wheel) 14
- Annual Inspection Programme 206
- Additional operations 206
- Ashtray
- Front 105
 - Rear 105
- ASR 120
- Automatic door locking 28
- Automatic electronic transmission (SPORTRONIC) 94
- Automatic fuel cut-off switch and power supply 128-263
- B**attery
- Advice for prolonging life 225
 - Battery charging 224
 - Battery maintenance 222
 - Starting with an auxiliary battery 194
- Before moving off 136
- Body maintenance 228
- Body versions 235
- Bodywork paint identification label 234
- Bonnet 112-265
- Boot 110
- Boot lifting and closing 111
 - Capacity 239
 - Charge anchorage 111
 - Emergency opening 111
 - Opening from inside 90-110
 - Opening from outside 110

Opening with remote control	110	Central locking	29	Clutch
Boot light		Charge anchorage	111	Checking fluid level & topping up..
Bulb replacement	185	Changing the bulb		219
Brake and clutch fluid		Bulb types	165-166	CO ₂ emission at the exhaust
Checking the level and topping up....	219	General instructions	165	243
Brake Assist (brake assist in an		Check Panel	72	Coin holder.....
emergency)	119-141	Child safety	30	104
Brakes		Child safety device (doors)	30	Combined activated carbon
Checking the fluid level & topping up..	219	Cigar lighter	105	pollen/dust filter
Handbrake	93	Cleaning and maintenance		87-222
Servo brake	140	Body	228	Compact Disc player
Specifications	243	Car exterior	229	125
Warnings	140	Car interior	231	Controls.....
Bulb replacement	165-181	Engine bay	230	90
Bulb types	165-166	Plastic parts	232	Controls on steering wheel (Alfa Romeo
		Seats.....	231	I.C.S. system).....
		Windows	230	14
Car maintenance	201	Climate control unit controls	84	Correct use of the car.....
Card holder	104	Clothes hooks.....	106	133
Carrying children safety	45			Courtesy light
				Changing the bulb
				182
				Cruise Control
				64
				D ashboard.....
				68-258
				Lighting adjustment
				91
				Data plates.....
				234
				Defrosting-Demisting
				85

Rearscreen	85	Driving	Electronic control units	226
Wing mirrors.....	37	At night	Emergency starting	
Diesel filter		Before moving off	(low battery)	136
Water purge	222	Economically & respecting the	Emergency starting (engine lock)	21
Direction indicators		environment	Emission control devices	130-131
Changing front bulbs (gas discharge)	171	In adverse weather	Engine	
Changing front bulbs (halogen)	175	In the mountains	Engine compartment lid opening ..	112
Changing rear bulbs	179	In winter	Heating	135
Changing side bulbs	177	Safe driving	Identification codes	234
Control lever	59	Stationary vehicle	Switching off	135
Door lights	107	Travelling	Technical data	237
Bulb change	184	Dust/pollen filter (combined	Engine codes — Body versions	235
Doors		activated carbon)	Engine compartment (washing)	230
Automatic locking	28	87-222	Engine compartment cover	112
Central locking	29	E conomy driving	Engine control system (EOBD)	116
Child safety	30	148	Engine coolant fluid	
Closing/opening from inside	29	Electronic alarm system	Checking the level & topping up ..	217
Closing/opening from outside	28	Cutting out the siren	Temperature gauge and warning light	74
Remote control.....	17-22	Electronic automatic gearbox	Engine lock (Alfa Romeo CODE)	21
		(Sportronic)		
		93		

Engine oil	Gas discharge headlights	167	Fuel tank cap	127
Checking the level	Halogen bulb headlights	171	Fuel flap	91
Consumption.....	Front roof lamp.....	106	Fuel oil filter	
Filling	Changing bulbs	181	Water purge	222
Topping up	Front seats.....	31	Fuel reserve	73
Engine oil consumption	Centre armrest	34	Fuses and relays	186-266
Engine starting	Electric adjustment.....	32	General	186
Environment safeguarding	Electric heating.....	31-32	In control box	187
EOBD (engine control system)	Headrest	33	In engine compartment	188
	Manual adjustment	31	In luggage compartment.....	190
	Rear pockets.....	34	List of protected devices	191
F irst aid kit	Fuel			
Flashing (high beam headlamps)	Automatic lock switch.....	128	G ear shift	
Fluids (specifications)	Filling	238-268	Lever	92
Fog lamps	Fuel consumption	242	Technical data	244
Aiming.....	Fuel flap opening.....	91	Getting the best	
Changing bulbs	Fuel flap opening in emergency	127	out of your car	133
Switching on.....	Fuel level gauge and low level		Getting to know your car	11
"Follow me home" device	indicator.....	73	Glovebox	102
Front light units			Grab handles	106

H andbrake lever	92	Inside rear-view mirror	36	Aiming for rh/lh drive	115
Hazard warning lights	90	Instrument panel	68-260	Changing bulbs (gas discharge headlights)	167
Headlamp washer	62	Interior equipment.....	102	Changing bulbs (halogen bulb headlights)	172
Headlamps.....	113	Interior maintenance	231	"Follow me home" device.....	60
Aiming device	92	J ack		Switching on.....	58
Driving low beam headlamp aiming for rh/lh drive	115	Use	161	Lubricants (specifications)	245
Gas discharge headlamps	114	Warnings.....	158-159	Luggage compartment	110
Headrests		K eys.....	16	M aintenance	
Front	33	Battery replacement.....	19	Additional operations	206
Rear	35	Emergency sunroof key	109	Annual Inspection Programme	206
High beam headlamps		L evel checking, refilling and replacement	209	General	203
Changing bulbs (gas discharge headlights)	167-169	Light switch	57-262	Maintenance programme	204
Changing bulbs (halogen bulb headlights)	173	Light units (front)		Precautions.....	202
Switching on.....	58	Gas discharge headlights	167	Scheduled Maintenance	202
In an emergency	157	Halogen bulb headlights	171	Mileage recorder	72
In the event of an accident	198	Low beam headlamps			

N umber plate lights		
Changing bulbs	179	
O ddments compartments.....	103-104	
Oddment compartment light		
Bulb change	183	
P arking lights	58	
Parking sensors.....	67	
Partial speedometer reset	72	
Performance.....	241	
Position lights		
Front bulb change (gas discharge)	167	
Front bulb change (halogen)	174	
Rear bulb change	178-179	
Switch on.....	58	
Power steering		
Checking the level & topping up	218	
Warnings	142	
Power steering oil		
Checking & topping up the level.....	218	
Power windows	38	
Front doors.....	38	
Rear doors	39	
Protection under the engine	214	
R adio	124	
Rain sensor	61	
Rear fog guards		
Changing bulbs	178	
Switching on.....	91	
Rear roof lamps	107	
Changing bulbs	182	
Rear seat	35	
Centre armrest	35	
Headrest	35	
Ski compartment.....	35	
Rearscreen heating	85	
Refuelling	125-238	
Relay	186	
In control box	187	
In engine compartment	188	
In luggage compartment.....	190	
Remote control	17-22	
Alarm system	22	
Battery change	19	
Door opening-closing	26	
Ministry certification	26-253	
Reversing lights		
Changing bulbs	178	
Right hand drive version	257	
RPM counter.....	73	
S afe driving	136	
Safeguarding the emission control		
devices	150	
Safeguarding the environment	130	

Safety belts	40	Steering column stalks	57	Technical specifications	233
Central rear seat	41	Steering lock	27	Telephone (provision)	107
General cautions about use	43	Steering system controls		Third stop light (bulb change)	180
Height adjustment	41	(Alfa Romeo I.C.S. system)	14	Tow hook	153-154
Maintenance	44	Steering wheel (adjustment lever)	36	Towing the car or another vehicle.....	196
Pre-tensioners	42	Stop lights		Version with electronic automatic	
Use	40	Changing bulbs	179	transmission	99
Scheduled Maintenance Programme.....	204	STR system (SPORT THROTTLE		Towing trailers	152
Servobrake	140	RESPONSE)	63	Transmission	244
Ski compartment	35	Sun visors	106	Travelling	137
Snow chains.....	147	Sunroof	108	Tyre pressure.....	145-249-268
Spare wheel	247	Emergency manoeuvre	109	Tyres	
Spark plugs	227	Opening-closing	108	Correct reading	250
Speakers	124	Raising the rear.....	109	Inflation pressure	249-268
Speedometer	72	Supply/ignition	240	In the event of a puncture.....	158
Spray jets	228	Switching off the engine	135	Snow chains	147
Starting device	27	T ailgate	110	Types of tyres and rims.....	247
Starting with an auxiliary battery.....	194	Technical data.....	233	Winter tyres	147
Stationary vehicle	138				

U seful accessories	156		
V DC and ASR systems	120		
Practical advice.....	141-142		
Vehicle data plates	234		
Vehicle dimensions	236		
Vehicle identification	234		
Vehicle inactivity	155		
Vehicle lifting			
Jack	197		
In the workshop	198		
Vehicle lifting points.....	197		
Vehicle maintenance	201		
W arning lights	74		
Weights	239		
Wheel balancing	146		
Wheel rims.....	247		
correct reading	251		
		W heels	
		Balancing	146
		Practical advice	143
		Replacement.....	159
		Snow chains.....	147
		Spare wheel	247
		Tyre inflation pressure	249
		Tyres and rims.....	247
		Windows	
		Cleaning.....	230
		Precautions.....	142
		Windscreen/headlamp washer	
		Checking & topping up the level	220
		Operation	62
		Spray jets.....	228
		Windscreen wiper	
		Changing the blades	227
		Rain sensor.....	61
		Speed selection	61
		Windscreen wiper blades	
		Changing the blades	227
		Practical advice	142
		Wing mirrors	37
		Winter driving.....	139

SELENIA®

***In the heart of those who race.
At the heart of your engine.***



Always ask your mechanic for **SELENIA®**

Your car is factory filled with Selenia

*The engine of your car is factory filled with **Selenia**, This is an engine oil range which satisfies the most advanced international specifications. Its superior technical characteristics allow **Selenia** to guarantee the **highest performance and protection** of your engine.*

The Selenia range includes a number of technologically advanced products:

SELENIA 20K ALFA ROMEO

API SL Lubricant which guarantees maximum wear protection and performance of aspirated, turbocharged and multivalve engines. Specific Selenia formulation for Alfa Romeo.

SELENIA RACING

This lubricant has been developed as a result of Selenia's extensive experience in track and rally competitions, it maximises engine performance in all kinds of competition use.

SELENIA TD

Oil for aspirated and turbocharged and multivalve diesel engines, guarantees excellent engine cleanliness and stability even at very high temperatures.

SELENIA WR

Oil specifically designed for common rail Multijet engines. Particularly effective during cold starts, it guaranteed maximum wear protection and hydraulic tappets control, reduction in consumption and stability at high temperatures.

The range also includes Selenia 20K, Selenia Performer 5W-30 e 5W-40, Selenia Digitech.

For further information on Selenia products visit the web site www.fl-selenia.com.





TYRE INFLATION PRESSURE COLD (BAR)

		Tyres 205/55 R16 91W (*)		Tyres 215/55 R16 93W		Tyres 225/45 R17 91Y		Tyres 235/40 R18 91Y	
		front	rear	front	rear	front	rear	front	rear
Reduced load (2 occupants)	bar	2.3	2.3	2.3	2.3	2.7	2.5	2.7	2.7
Full load	bar	2.3	2.3	2.3	2.3	2.7	2.5	2.7	2.7
Spare wheel	bar	2.3		2.3		2.7		2.7	

(*) For versions/markets where applicable

Tyre pressure should be increased by 0.3 bar when driving at sustained high speed. With winter tyres the pressure should be +0.2 bar higher than the rating specified for standard tyres.

ENGINE OIL REPLACEMENT (litres)

	2.0 T.SPARK	2.5 V6 24V	3.0 V6 24V (Sportronic)	3.2 V6 24V	JTD	JTD 20V Multijet	JTD 20V Multijet (Sportronic)
Engine oil (quantity for periodical change, including the oil filter change)	4.40	5.90	5.90	5.90	5.50	5.0	5.0

Do not discard used oil in the environment

REFUELLING (litres)

	2.0 T.SPARK	2.5 V6 24V	3.0 V6 24V (Sportronic)	3.2 V6 24V	JTD	JTD 20V Multijet	JTD 20V Multijet (Sportronic)
Fuel tank capacity	69	69	69	69	69	69	69
Reserve (litres)	9	9	9	9	9	9	9

Only use unleaded petrol with no less than 95 R.O.N.

Only use Diesel fuel for motor vehicles that meet European Specification EN590.



SERVICE

AFTER SALES

ASSISTENZA TECNICA - INGEGNERIA ASSISTENZIALE

Viale Alfa Romeo 20020 Arese (MI) - Italia

Fiat Auto S.p.A.

Publication no. 60431353 - 4th Edition - 09/2004

Printed by Satiz - Turin (Italy)

All rights reserved. Reproduction, even in part is prohibited without written permission from Fiat Auto S.p.A.

Coordinamento Editoriale Satiz - Torino